

DHK-7 and DLK

1. CONNECT POWER

- Open the cover and snap the battery inside into the battery clip. Replace cover.
- On units powered by AC, plug in power.



2. ADJUST DEPTH

Loosen the thumbscrew "collar" and slide the pipe to desired position.



3. MAINTENANCE

The guard around the float switch can be unscrewed to inspect or clean the float.



ADJUSTING DEPTH

OTHER NOTES

The enclosure is waterproof and can be sprayed down with a hose.

Apr 7, 2020